DRYER

1. Open the dryer door and insert the laundry
2. Do not overload the drum!
3. Choose the drying program by rotating the program selector knob in either direction.
4. Confirm the program selection by pressing the button under the program.
5. Clean the lint filter after every drying cycle!