



# Laundry Payment

1

## Choose your machine

Check if the machine is available and choose your machine with the button.



2

## Scan your step

Scan your bank card when the machine to be started appears on the screen.

Go to the machine and follow the instructions there.



Washing machine 1



Washing machine 2



Drying drum A 40 min



Drying drum B 40 min

